



AQUAEKO Heating & Hot Water Control User Guide

AQUAEKO App User Guide




Log-In Screen



Download App from Play Store for Android or App Store for iPhone. Enter email address for verification. Enter details for Unit ID and Serial Number as found in Touchscreen Menu, Cloud Info Screen.

Dashboard




From the Dashboard you can see the status of Zones.

See how much water is currently in the Cylinder.

Amount of boost remaining. Touch here to enter the Zone Timers Screen.


QuickBoost



Touch here to Quickboost Hot Water and to select the required quantity


Touch here to Quickboost Heating (Image shows heating boosted by 30 minutes)

Main Menu




← Touch here to Enter the Main Menu

Main Menu




From the main Menu gain access to the Dashboard, Heating and Hot Water Zone Timer Lists, View or change Default Zones, access Holiday Mode or view the User Guide.

Heating Zone List




Touch a Zone to gain access to view or adjust timers for that Zone

Hot Water Zone List




Touch a Zone to gain access to view or adjust timers for that Zone.


Heating Zone




Add a Zone Timer




Timer Added



Jumping Between Zones



AquaEko Zone




Current Status

Touch here to Boost

Touch here to Add a new Timer

Zone Timers

Add an AquaEko Timer




Touch here to Add a new Timer

Choose an ON time, pick which days to run and press SAVE.

Don't forget to select how many showers or baths to heat water for.

AquaEko Timer Added




Timer has been added. You can add up to 10 timers per zone

Touch here to activate or deactivate a timer

Touch here to delete a timer


Touch here to select how many showers or baths to heat water for.

Default Zones




The Default Zones Screen is used to select which hot water or heating zones appear and can be boosted from the Dashboard.

Holiday Mode




Touch here to engage Holiday Mode

Holiday Mode




Choose a START date and an END date. The Holiday period will be highlighted in green. During the Holiday period all timers are suspended. Press SAVE.

Holiday Mode Dashboard



Dashboard display when Holiday Mode is switched ON


Holiday Mode Engaged




Boosts cannot be activated once holiday mode has been engaged

AQUAEKO Touchscreen Guide






Home Screen Dashboard




Main Dashboard: From here the user can get quick access to Boost and Timer screens for both heating (on left) and hot water (on right). The user can adjust temperature for the heating zone where the touchscreen is mounted. The user can also access the main menu.



The Installer Set-up Screen allows access to menu items for adjusting AquaEko and Zone parameters.




1. AquaEko Boost Screen: Pressing the AquaEko Boost button on the Dashboard enters this screen. From here the user can boost/request a specific volume of hot water.



2. one List Boost Screen: From here the user can choose which Zone they would like to Boost by entering a Zone Boost Screen.




Zone Boost Screen: From here the user can boost heating by a number of minutes by pressing the + or — buttons or switch to constantly on by pressing the red button.




Zone Boost Screen: Showing 30 minute boost of Zone 2.




Zone Boost Screen: Showing Zone 2 switched to constantly on.




3. Zone List Timer Screen: From here the user can choose which Zone they would like to enter to view timers. Status information about which zones are currently running can also be viewed here.




Heating Timer Screen: From here the user can set and adjust timers. Up to 10 timers per zone can be in use at any one time. To set a timer, select an 'on' time, an 'off' time, which days to be active and switch the timer on to make it active.



4. AquaEko Timer Screen: From here the user can set and adjust timers. Up to 10 timers per zone can be in use at any one time. To set a timer, select an 'on' time, volume of water to be heated, which days to be active and switch the timer on to make it active.




Temperature of the default Heating Zone can be adjusted by using the + and — buttons. The current temperature of the default heating zone is displayed at the top left of the screen.




Main Menu: From here the user can select Holiday Mode or view the Cloud Information screen.


The Cloud Information screen displays the Unit ID and Passcode which is used to log-in to the Phone App.



Holiday Mode: Set a start date and an end date during which all timers will be inactive and confirm by switching from Off to On. The system will switch on for frost protection below the set temperature during the active holiday mode period.



When Holiday Mode is active the main dashboard will look like this. Functionality is disabled until Holiday Mode naturally comes to an end or is switched off through the Menu.



The Cloud Information Screen presents status information and the Unit ID and Passcode required to log in to the App.

+353 1 403 1200 UK: + 44 1244457818
info@systemlink.eu www.systemlink.eu

systemlink
Technologies